

# Hestia 1000 Bay Guillotine

## BASIC INSTALL SHEET



Version 1 04/12/24


Contents of manual may be updated without notice.

For the latest version of this manual please refer  
to our website: [www.livingfire.com.au](http://www.livingfire.com.au)

**PAUL AGNEW** | **DESIGNS**

# Hestia 1000 BAY GUILLOTINE

## FIREBOX DIMENSIONS




**Note:** External trim not included with the unit.

# Hestia 1000 BAY GUILLOTINE

## HEBEL ENCLOSURE

### SIDE VIEW



\* Min. Required flue length: 4metres

**HEBEL ENCLOSURE**

25 Min. Clearance

Combustible Ceiling

PAD 8" Insulated Ceiling Ring

PAD 8" Insulated Flue\*

PAD 8" Insulated 8"-8" Adaptor

37,500mm<sup>2</sup> Air vent

75 Hebel

37,500mm<sup>2</sup> Air vent

205

75 Hebel

6 Cement Sheet

300

300

6 Cement Sheet

PAD 8" Insulated Cowl

450

1950

2400

850


Combustible Wall

**PAUL AGNEW** | DESIGNS

# Hestia 1000 BAY GUILLOTINE

## HEBEL ENCLOSURE

### TOP VIEW



### HEBEL PANEL DIMENSION

