

Hestia 1000 Peninsula Guillotine

BASIC INSTALL SHEET



Version 2.2 12/03/25


Contents of manual may be updated without notice.

For the latest version of this manual please refer
to our website: www.livingfire.com.au

PAUL AGNEW | **DESIGNS**

Hestia 1000 PENINSULA GUILLOTINE


FIREBOX DIMENSIONS WITHOUT EXTERNAL FRAME



Note: External trim not included with the unit.

Hestia 1000 PENINSULA GUILLOTINE

FIREBOX DIMENSIONS WITH EXTERNAL FRAME



Note: External trim not included with the unit.

HEBEL ENCLOSURE

25 Min. Clearance

PAD 8" Insulated Cowl

Combustible Ceiling

PAD 8" Insulated Ceiling Ring

PAD 8" Insulated Flue*

450

37,500mm² Air vent

75 Hebel

100 Air Gap

Combustible Wall

75 Hebel

205

75 Hebel

37,500mm² Air vent

75.0 Hebel

300


6.0 Cement Sheet

PAUL AGNEW | DESIGNS

Hestia 1000 PENINSULA GUILLOTINE

HEBEL ENCLOSURE


FRONT VIEW



* Min. Required flue length: 4metres

Hestia 1000 PENINSULA GUILLOTINE

HEBEL ENCLOSURE



HEBEL PANEL DIMENSION

