

# onyx

## Avanti Electric


LED ELECTRIC FIRE RANGE  
with Thermostatic Remote Control



**Instructions for Use, Installation & Servicing  
For use in AU & NZ (Australia & New Zealand)**

## TECHNICAL SPECIFICATION


AVANTI 110RW	AVANTI 150RW	AVANTI 190RW
228-025AZ	228-031AZ	228-044AZ




MODEL	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P
Avanti 110RW	1154	628	1118	443	1100	425	111	442	66.5	445	862	300	336	22	12	215
Avanti 150RW	1554	628	1518	443	1500	425	111	442	66.5	445	1284	300	336	22	12	215
Avanti 190RW	2004	628	1968	443	1950	425	111	442	66.5	445	1764	300	336	22	12	215

## PRE-INSTALLATION





### DECORATIVE FRAME




### RIGHT VIEWING FACE








### FRONT VIEWING FACE




## PRE-INSTALLATION



LEFT VIEWING FACE






MOUNTING BRACKET




## INSTALLATION




### INSTALLATION METHOD 1




### INSTALLATION METHOD 2





110RW x4  
150RW x6  
190RW x6







**ALL METHODS**






**FRONT VIEWING FACE INSTALLATION**






AVANTI	A	B
110RW	1138	641
150RW	1538	641
190RW	1988	641






**TWO SIDED VIEW INSTALLATION**




AVANTI	A	B
110RW	1128	635
150RW	1528	635
190RW	1978	635


3




6




4



7





5





## THREESIDED VIEW INSTALLATION



AVANTI	A	B
110RW	1130	638
150RW	1530	638
190RW	1980	638

