

Regency PG36 Reset Procedure

1. Open the bottom front louvre of the heater.

2. Press and release the reset button. This is the black button located on the left side of the fan grille.

3. Wait for approximately 3 seconds and the pilot sparks can be heard and seen. It will take 2 to 3 seconds for the flame to be lit.

NOTE: A period of 30 seconds must pass before another reset is attempted.



Location of Reset Button in Bottom Front of Heater