




Corner Installation Clearances from Combustibles

A =

B =



Standard Installation Clearances from Combustibles


C =

D =

E =

Hearth Dimensions

Minimum Square Hearth



Minimum Corner Hearth

